



Corner Sink Front consists of front frame with door attached floor kit including toe kick (3 piece set)

Position 2 cabinets on either side of the Corner Sink Front 36" from the wall to the face frame as shown

attach the Sink front to the face frame of both cabinets on either side

build up floor 4.5" with 2x4's and lay down floor on top Attach toe kick

All dimensions ,size designations given are subject to verification on job site and adjustment to fit job conditions.

Closeoutcabinet.com  
267.288.1200

This is an original design and must not be released or copied unless applicable fee has been paid or job order placed.

Designed: 2/21/2011  
Printed: 2/21/2011