

ROLLOUT TRAY



Layout all the components.



Attach rear brackets to rear of the cabinet 1" from the side wall at the height that you prefer at this point use only one screw in the center.



Screw the spacers to the frame of the cabinet using the screws provided.



Slide glide mechanisms into the rear brackets as shown.

ROLLOUT TRAY



Attach the glide mechanism to the frame of the cabinet through the spacers _pre-drill.



Attach orange clips to the bottom front of the drawer box as shown.



Attach drawer box to glide. After drawer glides in and out smoothly set the 2 remaining screws into each bracket.